

INSTALLATION GUIDE FOR PCGAB449MBK



SAFETY INFORMATION

Released Date: 2021-05-31

Wattage

33W

120Vac, 60Hz

Model No.

PCGAB449MBK

Ratings

Please read and understand this entire manual before attempting to assemble, install or operate the product.

WARNING

 RISK OF ELECTRIC SHOCK - Before beginning installation, turn off electricity at the circuit breaker box or the main fuse box.

CAUTION

- · For your safety, read instructions completely before beginning installation.
- If in doubt about electrical installation, consult a licensed electrician.

TOOLS REQUIRED










CARE AND MAINTENANCE


• Wipe clean using soft, dry cloth or static duster. Always avoid using harsh chemicals and abrasives to clean fixture as they may damage the finish.

If you need further assistance call Quoizel Customer Care at 1-800-645-3184 (9:00am - 5:00pm EST), or visit us on-line at www.quoizel.com.

PACKAGE CONTENTS



MOUNTING HARDWARE








BB Mounting Screw





CC Wire Connector





Outlet Box Screw


























Your installation is now complete! Restore electricity and save this sheet for future reference.